


POWER®

OPERATOR'S MANUAL
MANUEL DE L'OPÉRATEUR
MANUAL PARA EL OPERADOR



Hand Spin Wheel Balancer
Machine à équilibrer avec Lancement Manuel
Equilibradora a Lanzamiento Manual

JN620ホイール balancer

1058

091-0-Sept-01

A

0026422

0026234

0026855

0025760

0025770

0026856

0026424

B

4026233

4026235

0025096

4025546

0026630

C

0024840

7022049

4201451

0026329

0024839

D

0016660

0016669

4025021


0025135

E

4025291

F

09/2001



1

2

3

4

5

1059

091-0-Sept-01

A

4025557

0025149

B

C

0025325

7416031

7804625

7052090

D


7418051

E


0025509

F

09/2001



091-0-Sept-01



091-0-Sept-01

09/2001

6

5

4

3

2

1

1061


A

B

C


D

E



BOXER S 1200

0912001



1062

091-0-Sept-01

A

B

C

D

E

F

1

2

3

4

5

4026383

0025200

4201449

0026540

0025444

0025594

4201454

4025448

0025429

0025428

0025707


0026603

4201451

0026756

(UK) 0200716
(EUROPE) 0200101
(USA) 0200336


09/2001



BOXER S 1200

091-0-Sept-01

091-0-Sept-01



09/2001