


Pezzi di ricambio
Spare parts
Rechange
Ersatzteillisten
Repuestos



HELPER 4FD		TAB.A	11 / 11
------------	--	-------	---------

1	4-114895	CARTER CILINDRO	COVER CYLINDER
5	425219	VOLANTINO	KNOB
9	4-114928	DISCO	TRAY
10	4-114913	BRACCIO	ARM
11	5-104737	CONO CPL.	CONE ASSEMBLY
12	4-114927	RULLO	ROLL
13	4-114919	BARRA	BAR
15	4-114901	PERNO	PIN
16	4-114897	PIASTRA	PLATE
17	4-114884	PIASTRA	PLATE
22	5-104736	REGOLATORE DI PRESSIONE	PRESSURE REGULATOR
23	3093988	TUBO	HOSE
25	5-104725	CILINDRO	CYLINDER
27	4218738	BOCCOLA	BUSH
29	4-114907	PELLICOLA	PELLICLE
30	4-114883	PATTINO	SLIDING
31	4-114885	ALBERO	SHAFT
32	4-114902	TAMPONE	PAD
33	4-114903	PELLICOLA	PELLICLE
36	4-114882	PIASTRA DI SCORRIMENTO	SLIDING
37	4-114881	TELAIO	WELDED FRAME
39	4-115227	TUBO	HOSE
40	4-114886	COPERCHIO	COVER
41	4-114891	SUPPORTO	SUPPORT
42	4-114898	SCATOLA	BOX
43	4-114908	BRACCIO SUPERIORE	TOP ARM
46	4-114978	RONDELLA	WASHER
48	4-114911	BRACCIO	MID ARM
50	5-101552	VALVOLA	VALVE
51	4-113163	COPERCHIO IN PLASTICA	PLASTIC COVER
52	4-114951	UTENSILE	TOOL
53	321200	TUBO	HOSE
54	358385	TUBO	HOSE

