

部品図



**AIR-ELECTRIC  
TYRE CHANGER FOR CAR,  
LIGHT TRUCK AND  
MOTORCYCLE WHEELS**

---

OPERATOR'S MANUAL



385

1

2

3

4

5


A

B

C


D

E



386

1



A


B

C


D

E


2



3



5





388

1

2

3

4

5


A

B

C

D

E



392

1

2

3

4

5

6


A

B

C

D

E





1

389

2

3

4

5

6


A

B

C

D

E



4015652

0001255

7020339

7023059

0005643

7104189

Merano 95

7023119


4013082

7020111

0002486

7021119

4013078




4015650



357

1


A



0016334

2

3



0009353

4

5

7020479

7021082

0010241

0001775

7021082

0001404

0001368

B

0001402

0008752

0001203

C

D

0013010

E

4015652

8 08/95



387

1

2

3

4

5


A

B

C

D

E



4019331

10 11/92

391

1

A

B

C

D

E

7020091

7021232

0019337

7020091

7021232

7021232

0001432

7207099

0013460

0001431

0010944

7202239

7021232

0012282

0001432

4019325

// 11/95

